


Product Card

Cover Plates (partly incl. Insert) Level switch Turn button Symbol "0-1-2-3" - Saga



Control element/cover plate

Cover Plates (partly incl. Insert) Level switch Turn button Symbol "0-1-2-3" - Saga



Type: 2542 DR/01-916-510

Product ID: 2CKA001710A4161

GTIN: 4011395318140

Three-step rotary switch. With zero position

Technical specification

Classification

Suitable for degree of protection (IP):	IP20
---	------

Packing

Package:	1/1
Unit:	PCS

ETIM Data

ETIM Version:	ETIM-9.0
ETIM Class:	EC000011
Model:	Turn button
Imprint/indication:	Symbol "0"
Scannable symbol/barrier free:	No
Utilization:	Level switch
Suitable for touch sensor connector for bus system:	No
Type of fastening:	Clamp mounting
Monitoring window/light outlet:	No

© ABB 2025

Business ID 0763403-0

www.installationmaterials.com

Customer service

puh. +358 10 222 1999

contact.center@fi.abb.com

ABB Exchange

+358 10 22 11

Product Card

Cover Plates (partly incl. Insert) Level switch Turn button Symbol "0-1-2-3" - Saga



Material:	Plastic
Material quality:	Thermoplastic
Halogen free:	No
Surface protection:	Untreated
Surface finishing:	Glossy
Anti-bacterial treatment:	No
Colour:	White
RAL-number (similar):	9003
With label area:	No
With exchangeable lens/symbol:	No
Width:	70.8 mm
Height:	70.8 mm
Depth:	62.95 mm