


## Product Card

Cover Plates (partly incl. Insert) Level switch Turn button Symbol "0-1-2-3" - Saga



# Control element/cover plate

Cover Plates (partly incl. Insert) Level switch Turn button Symbol "0-1-2-3" - Saga



**Type:** 2542 DR/01-916-510

**Product ID:** 2CKA001710A4161

**GTIN:** 4011395318140

Three-step rotary switch. With zero position

## Technical specification

### Packing

Package:	1/1
Unit:	PCS

### ETIM Data

Model:	Turn button
Imprint/indication:	Symbol "0"
Scannable symbol/barrier free:	No
Utilization:	Level switch
Suitable for touch sensor connector for bus system:	No
Type of fastening:	Clamp mounting
Monitoring window/light outlet:	No
Material:	Plastic
Material quality:	Thermoplastic
Halogen free:	No
Surface protection:	Other
Surface finishing:	Glossy

# Product Card

Cover Plates (partly incl. Insert) Level switch Turn button Symbol "0-1-2-3" - Saga



Anti-bacterial treatment:	No
Colour:	White
RAL-number (similar):	9003
With label area:	No
With exchangeable lens/symbol:	No
Suitable for degree of protection (IP):	IP20
Width:	70.8 mm
Height:	70.8 mm
Depth:	62.95 mm